

# TIP

## Change setting groups manually to run commissioning tests faster

Sometimes testing the protection functions in each setting group can be laborious if changing the settings group activation requires a very specific condition. To work around this it is possible to temporarily change the setting group manually by enabling *Force SG change* and then choose the desired setting group with *Force SG*. If Live Mode-is activated, active setting group is displayed in *Active setting group*.

